

# Prevail™ Concentrate: 5 Gallon Eco-Container

## Quick Start Guide

### Components

1. Prevail Concentrate 5 gal
2. Opener/Bung Wrench

### If using a Pump

3. Hand Pump
4. Adaptor Fitting
5. Locking Unit
6. O-ring



For automated dilution systems, refer to the dedicated Quick Start Guide at [PrevailDisinfectants.ca](http://PrevailDisinfectants.ca).

Wrenches and the new improved pumps are available from your Prevail distributor.

## Step-by-Step



### 1. Wear chemical-resistant Gloves

Although Prevail Concentrate, once diluted, is non-irritating to the skin, gloves should be worn when handling the concentrate solution directly.

### 2. Attach the wrench

Place it on the container cap and rotate counter-clockwise to remove the lid.

### 3. Prepare the Pump

First slide the larger white adaptor fitting, then black o-ring, and finally the small white locking unit onto the shaft of the pump as shown.

### 4. Install the Pump

Place the pump into the container, ensuring the pump reaches the bottom of the container. Slide the locking unit down to the container opening, and screw clockwise until the pump is secure.

### 5. Prime the Pump

Open the blue safety handle, by pulling it down and away from the dispensing spout. Pump the handle until concentrate flows. Collect the concentrate in a bucket or container.

### 6. Dispense Concentrate

You're now ready to safely use your eco-container and hand pump. Use a measuring cup to ensure the correct dilution.



Prevail™ is a member of the Virox family of brands.

You must read and follow the instructions on the label for our product and use the product for the particular applications specified on the product label. AHP® and Design and Accelerated Hydrogen